

Fig. A2-8—View of transmission gears and shafts installed. Refer to Fig. A2-7 for legend.

the internal drive lugs bent in (toward the gear case). When adjusting the clutch spring nuts (17), tighten all nuts evenly until clutch does not slip. Springs can be adjusted through the small cover on right side cover after unit is assembled. Minimum clearance between adjuster nuts (17) and spring cups (15) is 0.06 inch as shown at (C—Fig. A2-6).

**CRANKCASE AND GEAR BOX.**

To disassemble the crankcase and gear box, the engine must first be removed. Remove the cowling, cylinder head, cylinder, piston, flywheel clutch and crankshaft gear. Remove screws that attach crankcase halves together and carefully separate the halves. Dowel pins are installed between halves. Be careful not to damage sealing surfaces of crankcase. The transmission is shown in Fig. A2-7.

Use light grease to hold the 17 loose rollers in the bearing cages (45 & 54) when assembling. Before installing the




Fig. A2-9—Refer to text when installing the kick starter pedal.

kick starter pedal (24), turn the starter shaft counter-clockwise until gear contacts case as shown at (A—Fig. A2-9). Install starter lever on shaft so that distance (B) between lever and front of screw is 1/4-1/2 inch, then hook return spring over lever.

# BENELLI

## 125CC MODELS

MODEL	COBRA, CALIFORNIA & SCRAMBLER
Displacement—cc	123.6
Bore—MM	54
Stroke—MM	54
Oil-fuel ratio	1 to 20
Plug gap—MM	0.55
Inch	0.022
Point gap—MM	0.4
Inch	0.016
Ignition timing—Advance	Fixed
Degrees BTDC	29
Tire size—Front	2.75 x 18
Rear	3.00 x 18
Tire pressure—	
Front—kg/cm <sup>2</sup>	1.54
Psi	22
Rear—kg/cm <sup>2</sup>	1.96
Psi	28
Rear chain free play—inch.	1/2
Number of speeds	4
Weight—Lbs. (Approx.)	205

**MAINTENANCE**

**SPARK PLUG.** Spark plug electrode gap should be 0.022 inch. Standard spark plug is Beru 1348/2.

**CARBURETOR.** Del'Orto ME 18 BS carburetor is shown in Fig. BE1-1. Idle speed is adjusted at screw (7). Idle mixture needle (6) initial setting is 1 turn open. Turning the needle counter-clockwise leans the mixture. Clip (1) should be in center (2nd notch of needle (3). Main jet (8) standard size is 76.

**IGNITION AND ELECTRICAL.** Ignition point gap can be checked and adjusted through slots in flywheel after the left side cover is removed. Point gap should be 0.016 inch (0.4MM). The flywheel and crankcase are marked to




Fig. BE1-1—Exploded view of Del'Orto carburetor. Idle mixture is adjusted at needle (6).

- 1. Clip
- 2. Throttle slide
- 3. Valve needle
- 4. Pilot jet
- 5. Minimum jet
- 6. Idle mixture needle
- 7. Idle speed screw
- 8. Main jet
- 9. Nozzle
- 10. Float
- 11. Choke slide




Fig. BE1-2—When notch on flywheel is aligned with notch on crankcase, crankshaft is positioned for correct ignition point. When "O" on flywheel is aligned with notch in crankcase, piston is at TDC.

indicate TDC and ignition timing (29° BTDC) as shown in Fig. BE1-2. Timing is changed by moving the magneto stator plate in the elongated mounting holes after removing the flywheel and loosening the three stator plate retaining screws. Ignition should occur (points just open) when the notched mark on flywheel is aligned with notch in crankcase. Flywheel rotates counter-clockwise.

**LUBRICATION.** The engine is lubricated by mixing two stroke motor oil with the fuel. Ratio should be 1:15 for the first 1,000 miles; 1:20 after 1,000 miles. The gear box is lubricated with 40 fl. oz. of SAE 30 motor oil. Gear box oil should be drained and refilled every 3,000 miles. Oil should be maintained between marks on filler plug dipstick at right rear of crankcase.

**CLUTCH CONTROLS.** The clutch cable should be adjusted to provide the hand lever with some free play. Adjustment can normally be accomplished at end of cable. Additional adjustment is possible by turning the adjusting screw




Fig. BE1-4—Exploded view of front suspension unit.

- |                           |                             |
|---------------------------|-----------------------------|
| 1. Top plug               | 11. Gaskets                 |
| 2. Steering friction knob | 12. Spring                  |
| 3. Fiber washer           | 13. Dampener                |
| 4. Friction nut           | 14. Lower sliding tube      |
| 5. Tube                   | 15. Retainer                |
| 6. Bushing                | 16. Washer                  |
| 7. Washer                 | 17. Oil seal                |
| 8. Plug                   | 18. Bushing                 |
| 9. Washer                 | 19. Screw for dampener (13) |
| 10. Screw                 |                             |

(20—Fig. BE1-6) in clutch lever under the engine left side cover.

**SUSPENSION.** Each front suspension unit is drained at plug (D—Fig. BE1-3). Fill to the level of filler plug (F) with SAE 20 motor oil. Fluid in the front suspension should be checked every 1,000 miles and drained every 5,000 miles. The rear suspension units are available only as complete assembly and should be renewed if bent, leaking or otherwise damaged.

**REPAIRS**  
**PISTON, RINGS AND CYLINDER.** The piston can be removed after removing fuel tank, exhaust pipe, carburetor, cylinder head and cylinder. Standard cylinder bore diameter is 54.0-54.015MM (2.165-2.166 in.). Piston to cylinder clearance should be 0.04-0.075MM (0.0016-0.003 inch) when measured at bottom of piston skirt at right angles to piston pin. Wear limit is 0.1MM (0.004 inch). Piston and rings are available in three oversizes. When installing piston, make certain that cut-away part of skirt is in toward rear (carburetor).

**CONNECTING ROD AND CRANKSHAFT.** The crankcase halves must be separated to remove the crankshaft. Connecting rod, crankpin and roller bearings are removed by pressing the crankshaft apart. Crankshaft should be disassembled ONLY if required tools are available to correctly check and align the reassembled crankshaft.

**CLUTCH.** The manual, multiple disc wet type clutch is mounted on the right end of the transmission input shaft as shown in Fig. BE1-6. The clutch is actuated by lever (21) on left side and rods (23 & 38) which go through center of the input shaft. The actuating block (39) is used as drive key and disengaging block. When reassembling, smooth side of pressure plate (47) should be toward retaining ring (48). Tighten nut (52) to 36 Ft.-Lbs. torque.

**CRANKCASE AND GEAR BOX.** To disassemble the crankcase and gear




Fig. BE1-3—Oil in front forks is drained at screw (D). Oil should be maintained at level of filler screw hole (F).




Fig. BE1-5—Oil level should be maintained between marks on dipstick attached to filler plug.




Fig. BE1-5A—View showing oil drain plug. Make certain that sealing washer is in good condition when replacing plug.

box, the engine must be removed. Remove the cylinder head, cylinder, piston, magneto assembly, clutch and crankshaft drive gear. Remove the four nuts and eleven screws and separate

the crankcase halves. Refer to Fig. BE1-6. When assembling, the gears and shaft can be assembled in the left half of crankcase and right half can be assembled over the shafts. The timing

marks on selector shaft (14) gear and shift drum (77) gear must be aligned. Check alignment of timing marks after assembly through hole in right crankcase half.




Fig. BE1-6—Exploded view of engine and transmission.

- |                                |                              |                        |                         |
|--------------------------------|------------------------------|------------------------|-------------------------|
| 1. Flywheel                    | 18. Shift forks and rail     | 38. Clutch rod         | 58. Gear (3rd)          |
| 2. Ignition low tension coil   | 19. Shift pedal              | 39. Actuating block    | 59. Sliding gear (2nd)  |
| 3. Lighting coil               | 20. Adjusting screw          | 40. Thrust washer      | 60. Output shaft        |
| 4. Stator plate                | 21. Clutch lever             | 41. Bushing            | 61. Bushing             |
| 5. Seals                       | 22. Bracket                  | 42. Clutch drum        | 62. Gear (4th)          |
| 6. Snap ring                   | 23. Short rod                | 43. Thrust washer      | 63. Bearing             |
| 7. Main bearings               | 24. Oil seal                 | 44. Snap ring          | 64. Seal                |
| 8. Bearing retainers           | 25. Ball                     | 45. Steel driven plate | 65. Output sprocket     |
| 9. Spacer                      | 26. Bearing                  | 46. Friction disc      | 66. Kickstarter ratchet |
| 10. Crankshaft gear            | 28. Gear (4th)               | 47. Pressure plate     | 67. Washer              |
| 11. Detent housing             | 29. Bushing                  | 48. Snap ring          | 68. Bushing             |
| 12. Detent for shift drum      | 30. Washer                   | 49. Clutch hub         | 69. Kickstarter gear    |
| 13. Centering springs & blocks | 31. Sliding gear (3rd)       | 50. Spring             | 70. Plate               |
| 14. Preselector                | 32. Snap ring                | 51. Washer             | 71. "O" ring            |
| 15. Selector shaft             | 33. Washer                   | 52. Nut                | 72. Kickstarter shaft   |
| 16. Ratchet pawls and spring   | 34. Gear (2nd)               | 53. Snap ring          | 73. Return spring       |
| 17. Shift fork rollers         | 35. Input shaft & gear (1st) | 54. Bearing            | 74. Washer              |
|                                | 36. Bearing                  | 55. Washer             | 75. Snap ring           |
|                                | 37. Snap ring                | 56. Gear (1st)         | 76. Lever               |
|                                |                              | 57. Bushing            | 77. Shift drum          |

Copyright of *Vintage Collection (Two-Stroke Motorcycles)* is the property of Penton Media, Inc. ("Clymer") and its content may not be copied or emailed to multiple sites or posted to a listserv without the copyright holder's express written permission. However, users may print, download, or email articles for individual use.