

## GENERAL NOTES

- Wood species = Spalted Maple. The wood can be sourced locally, but a sample piece will need to be sent to your Pancheros Project Manager/ Designer for approval prior to purchase and install. If you are unable to locate the product locally we do have an Iowa based source that can ship the product to you for \$6.00 SF + shipping. Planks will arrive without any finish. We want Spalted Maple with a lot of color variation. See provided photos as examples.
- Plank size = 4" height x 5/8" thickness x random cuts to fill area
- Install method = liquid nails on the back of each plank and 1 1/4" nails (from a nail gun).
- The wall returns should be done first with same size planks and no overhang. The front side of the wall will have planks that overlap the returns. See detailed drawings.
- Wood needs to mount to plywood or OSB to ensure it is secure. Drywall alone is not sufficient.
- Wood will be installed above wallcovering with chair rail installed over both. Wall transition from wallcovering to wood needs to be flush.

## INSTALL INSTRUCTIONS

- Prior to installing sand all planks to a smooth finish.
- Prior to installing spray or brush all planks with 2-3 even coats of Varathane Polyurethane in the satin finish. Using the Varathane product is crucial to keep the natural color of the wood. Other sealers will cause the wood to yellow. Sanding between coats to get a smooth finish is needed.



- Cut planks on front face of wall in random widths to create a varied plank look. See provided photos and drawings as examples.
- After install fill all nail holes with Minwax wood putty (non-sandable type) in the color Natural Pine. Wipe the surface clean of leftover putty and dust with a damp rag.



- Once dry give the wood one additional coat of the Varathane Poly and allow to dry prior to installing artwork.