

BLDG PAPER -

FLAP -


WATER PROOFING MEMBRANE APPLIED OVER STUDS & PLYWD

WATER PROOFING MEMBRANE APPLIED OVER STUDS & PLYWD -


WINDOW BOT. TRACK (SILL RECEPTOR) 3/8" SPACE

CONTINUOUS AROUND ENTIRE

THIS DIAGRAM SHOWS THE APPLICATION OF SILL RECEPTOR AND METAL SURFACE PRIOR TO APPLYING SILICONE GLAZING SYSTEM FIBER CEMENT PANELS - STOREFRONT WINDOW BODY INSERT FLASHING BELOW SILL RECEPTOR THEN CAULK WINDOW FLASHING -ALUMINUM FINISH TO MATCH STOREFRONT BACKER ROD & CAULK ON TOP OF SILL FLASHING NOTE: DO NOT CAULK / OBSTRUCT WEEP HOLES DRILLING IN SILL RECEPTOR







## WATER PROOFING ROUGH OPENING

AFTER FRAMING WATER PROOFING MEMBRANE PER FIBER CEMENT PANEL MANUFACTURER RECOMMENDATIONS. ADD FLASHING TAPE AROUND THE ROUGH OPENING FOR THE WINDOW AND DOOR OPENING.

